

Operation Guideline for QH100-PV Switching Module

QH100-PV switching module is developed by INVT for Goodrive100-PV series solar pumping inverter with the aim of achieving automatic mains and PV switching. Below is the functional block diagram for this module, in which the "voltage detection/judging circuit" outputs ON/OFF signal S,COM based on the preset threshold. This module can realize automatic mains and PV switching by combining with necessary low voltage apparatus.




Fig.1: QH100-PV functional block diagram

This guideline mainly introduces module installation and wire connection. In cases where it is required to work with Goodrive100-PV inverter, refer to "Operation Manual for Goodrive100-PV series Solar Pumping Inverter" for more details.

1. Type designation and specification

QH100 – 055A – 4 – PV

① ② ③ ④

Type designation illustration:

| Field identification | Sign | Detailed description | Content |
|---------------------------------|------|-----------------------------------|---|
| Abbreviation for product series | ① | Abbreviation for product series | QH100 series mains and PV switching module |
| Rated current | ② | Power range for adaptive inverter | 055A—adaptive to 0.4~15kW inverter 110A—adaptive to 18.5~37kW inverter |
| Voltage degree | ③ | Voltage degree | 4: AC 3PH 380V(-15%) ~ 440(+10%) 2: AC 3PH 220V(-15%) ~ 240(+10%) |
| Code | ④ | Industry code | PV: Photovoltaic water pump series |

2. Installation and dimension




Fig.2: Installation dimensions (unit: mm)

Caution: In order to ensure safe and reliable operation of this product, extra cooling method (such as a DC fan) is required.

3. Recommended wire connection




Fig.3: Recommended connection diagram

Terminal instruction:

| Terminal symbol | Terminal name | Terminal function |
|-----------------|--------------------------|--|
| PV+ | PV input | Voltage detection board input, anode of diode module, connect with PV input anode |
| PV- | | Voltage detection board input, connect with PV input cathode |
| (+) | Switching module output | Cathode of diode module, connect with inverter (+) |
| S,COM | Voltage detection signal | ON/OFF signal, corresponding PV voltage greater/less than preset threshold, connect with HDI, COM terminal of the inverter |

4. Parameters setting

When using QH100-PV to work with Goodrive100-PV Inverter, set the parameters as below:

| Parameter | Only PV input | Only mains input | Mains / PV switching |
|-----------|---------------|------------------|----------------------|
| P15.32 | 2 | 1 | 0 |

5. Product and Service Inquires

Address any inquires about the product to your local INVT offices, quoting the type designation and serial number of the unit in question. A list of INVT offices can be found on www.invt.com.cn.



Part number: 66001-00453

INVT Copyright.

Information may be subject to change without notice during product improving.

201608(V1.0)