

Assembly instructions

Assembly packing list

Width 600mm

Screw M5 Screw M6 Door pin Screws M8 Handle lock Casters Feet Latches

Top cover Bottom Side panel Rear door Glass door Frame Vertical profile Horizontal profile

Width 800mm

Bracket Doorstop Rail support

Split door & door pin

Step 1: Fix the top cover and bottom on frames with M8 screw; Fix the casters.

Top cover **Bottom** **Caster**

M8 x 8sets M8 x 8sets M5 x 16pcs

Step 2A: Fix width 600mm cabinet mounting rails and mounting profile with M5 screw;

Upper and bottom rails Fix upper and bottom mounting rails at the third round hole as picture, each with 8pcs M5 screws

Middle rail Fix the middle horizontal mounting rail at the sixth round hole from the location without square hole

Fix 4 vertical mounting profiles on the mounting rails, each with 3pcs M5 screws.

M5 x 8pcs

Assembly instructions

Step 2B: Fix width 800mm cabinet

1. Fix bracket on the mounting rails, each with 4pcs M5 screws.

2. Fix 2pcs rail support on the frame, each with 4pcs M5 screws.

3. Fix vertical mounting profile on the bracket, each with 3pcs M5 screws. And please put the mounting profile on the rail support closely.

Step 3: Fix doors and side panels ;

Fix front and back door pins, fix the doors and side panels. Split doors, please fix the doorstop on the top and bottom.

Side door

Fix handle latches on the side panel

Step 4: Fix the lock on the door;

Front door

Fix handle lock on the doors

Split doors

Fix handle lock on the doors
Fasten the door pin on the lock

Complete!
Thank you!